



THE TIME & TEMPERATURE COMPANY™

Model: DTP392

Probe Thermometer

32 to 392°F/0 to 200°C

Perfect For

- Roasts & other meats
- Candy making & deep fry

Easy To Use

- Instant readout of internal food temperature during cooking
- Audio/visual alert sounds when set temperature is reached


Features

- 5.5"/14 cm probe
- 3'/91 cm sensor cable
- Shatterproof
- Dual progress display
- Big digit
- Food-safe ABS plastic case
- Stainless steel probe
- Sliding mode switch
- Temperature guide
- 2-way mounting: magnet/stand
- Adjustable stainless steel clip
- Battery and instructions included

Get Professional Results Every Time!

Perfect for roasting or grilling. Simply insert the probe into the food. Place the food in the oven or barbecue and close the oven door (or grill cover) directly over the sensor cable. Set the temperature alert for USDA safe cooking temperatures. Both the set and actual temperatures are displayed during cooking.

Note: Remove sticker from display before use.



Note: In the following instructions, names of the control buttons are shown in CAPS. Function information that appears on the display is shown in **BOLD CAPS**.

Battery Installation

Replace battery when LCD becomes dim or alert level declines.

1. Remove battery cover on the back by sliding it in the direction of the arrow.
2. Install one 1.5V AAA battery observing polarity shown in compartment. A brief alarm sounds.
3. Replace the battery cover until it clicks shut.
4. **LO** will be displayed under **COOKING TEMP** when the probe/sensor cable is disconnected or malfunctions.

Operating Instructions

A. Temperature Scale


Slide switch to °F or °C on the back of the case to select temperature reading in Fahrenheit or Celsius.

B. Temperature Alert

1. Slide alert switch on the left side of the case to ON to turn the audio/visual alert on.
2. Insert the probe at least 1" (2.5 cm) into the meat; making sure that it is not inserted into a fatty deposit.
3. Gently close the oven door on the sensor cable and insert the plug into the jack on the right side of the case.

4. Press the UP or DOWN button to set the desired temperature under **ALERT TEMP**.
5. The alert sounds when the cooking temperature reaches the alert temperature.
6. Press STOP to stop the alert.

C. Candy Thermometer

1. **As a matter of safety, always position the probe on the pot before filling it and/or applying heat.**
2. Insert the probe through both holes in the attachment clip. Press the top portion of the clip together for easier sliding up the probe. 
3. Push the clip down onto the side of the pot and position it until the probe tip is just above the bottom. **Do not let the tip touch the bottom of the pot.**
Important: Keep sensor cable away from direct heat of the cooktop burner – wires inside the cable may become damaged.
4. Set the alert temperature as described in **B4**. Candy temperatures are listed here for easy reference.

Note: Clean the thermometer probe before each use.

Important: DO NOT LEAVE THERMOMETER CASE IN HOT OVEN. IT IS NOT HEAT RESISTANT. DO NOT USE PROBE IN MICROWAVE OVENS.

Tip: Meat should be allowed to “rest” for 10 to 15 minutes after it is removed from oven. This allows time for the meat’s internal temperature to stabilize and the juices to redistribute. This will result in a roast that is both juicier and easier to carve.

Precautions

- Always wear a heat resistant glove to touch the stainless steel probe or sensor cable during or just after cooking.
Do not touch with bare hands.
- Keep the battery, stainless steel probe and sensor cable away from children.
- Clean the probe and dry thoroughly after use.
- Do not clean the case with abrasive or corrosive compound, which may scratch the plastic and corrode the electronic circuits.
- Do not subject the unit to excessive force shock, dust, temperature or humidity, which may result in malfunction, shorter electronic life span, damaged battery and distorted parts.
- Do not tamper with the unit’s internal components. Doing so will invalidated the warranty on the unit and may cause unnecessary battery damage and distorted parts.
- Do not subject the unit to excessive exposure to direct sunlight. **The unit is not waterproof** – do not immerse it into water or expose to heavy rain.

- Do not expose the sensor cable plug or the jack on the case to water or any liquid, which will result in a bad connection and faulty readings.
- To avoid deformation, do not place the unit in extreme temperatures. Never burn the probe directly over the fire. Do not use the probe when the temperature is above 392°F/200°C. Doing so will deteriorate the wire.
- Do not use the probe in a microwave oven.
- Always read the users manual thoroughly before operating.

Specifications

Temperature Alert: 32 to 392°F/0 to +200°C; °F/°C selectable
Power: 1 DC 1.5V AAA Alkaline battery

Note: During the electrostatic discharge, the device may malfunction. Please press any key to return to normal operation.



CANDY TEMPERATURE GUIDE	
Jelly	220°F 104°C
Thread	230–234°F . . . 110–112°C
Soft Ball	234–240°F . . . 112–115°C
Firm Ball	244–248°F . . . 118–120°C
Hard Ball	250–266°F . . . 121–130°C
Soft Crack	270–290°F . . . 132–143°C
Hard Crack	300–310°F . . . 149–154°C
Caramelize	316–338°F . . . 158–170°C

OIL TEMPERATURE GUIDE
325–375°F/163–190°C is the normal desired temperature for deep fry cooking.
Note: When food is added to hot oil, the temperature of the oil immediately drops at least 50°F/28°C. You will need to bring the oil temperature back to the desired cooking temperature. Frying at lower temperatures results in lighter color, less flavor development and increased oil absorption.

DEEP FRY TEMPERATURE GUIDE

Deep Fry Lo	...325-340°F	...163-170°C
Deep Fry Hi	...340-365°F	...170-185°C
Shrimp350°F177°C
Chicken355°F180°C
Onions370°F188°C
Fish375°F191°C
Doughnuts/Fritters	.375°F191°C
French Fries380°F193°C

MEAT TEMPERATURE GUIDE

Beef, Veal, Lamb,		
Pork – well170°F77°C
Poultry165°F74°C
Beef, Veal, Lamb,		
Pork – medium160°F71°C
Beef, Veal, Lamb		
– medium rare145°F63°C
Beef – rare;		
Ham – pre-cooked	.140°F60°C

The information in this document has been reviewed and is believed to be accurate. However, neither the manufacturer nor its affiliates assume any responsibility for inaccuracies, errors or omissions that may be contained herein. In no event will the manufacturer or its affiliates be liable for direct, indirect, special, incidental or consequential damages arisen by using this product or resulting from any defect/omission in this document, even if advised of the possibility of such damages. The manufacturer and its affiliates reserve the right to make improvements or changes to this document and the products and services described at any time, without notice or obligation.



5-Year Limited Warranty: Any instrument that proves to be defective in material or workmanship within five years of original purchase will be repaired or replaced without charge upon receipt of the unit prepaid at: CDN, PO Box 10947, Portland, OR 97296-0947. This warranty does not cover damage in shipment or failure caused by tampering, obvious carelessness or abuse.



Component Design Northwest, Inc.
PO Box 10947
Portland, OR 97296-0947
Tel 800 338-5594
Fax 800 879-2364
Web www.cdn-timeandtemp.com



*USDA does not endorse any product, service or organization.